

SIMPLE WEIGH™

TONGUE WEIGHT SCALE

| Model | Maximum Capacity |
|------------|------------------|
| 88-00-3720 | 2,100 lb |

Instructions

1. Park your trailer on a level, flat, solid surface - preferably concrete or asphalt.
2. Chock and uncouple the trailer.
3. Move the tow vehicle forward until the hitch ball is not below the coupler socket.
4. Place the SIMPLE WEIGH™ scale directly below the trailer coupler socket. Use blocks if needed to raise the scale up.
5. Slowly retract the tongue jack until the jack foot is about 1" above the ground to allow the full weight of the trailer tongue to rest on the scale.
6. Support the trailer with only the tongue scale, no stabilizer jacks.
7. Read the weight indicated on the scale.
8. Slowly raise the tongue jack and ensure the trailer is secure before removing the SIMPLE WEIGH.



Important Info

Additional blocks may be placed under the scale so the trailer can be weighed in a position parallel to the ground.

Keep the scale free of dirt, dust, salt and water.

The Fastway® SIMPLE WEIGH™ scale is not certified for trade. Scale results will vary and are approximate.

Store with your trailer or in a safe place inside your tow vehicle to perform the measurement before each trip.

Customer Support


If you need customer support, or replacement parts and accessories, please contact our customer support team. Please call us at 877.523.9103, send us an email at support@fastwaytrailer.com or use the chat feature on fastwaytrailer.com. Our team is available Monday through Friday, 8AM to 5PM (Mountain Time).

Find us Online

We would love to connect with you. Find us on these social media platforms.


- ▶ [youtube.com/fastwaytrailer](https://www.youtube.com/fastwaytrailer)
- ▶ [facebook.com/fastwaytrailer](https://www.facebook.com/fastwaytrailer)
- ▶ [twitter.com/fastwaytrailer](https://www.twitter.com/fastwaytrailer)
- ▶ [instagram.com/fastwaytrailer](https://www.instagram.com/fastwaytrailer)

Visit Fastway® Trailer Products at www.fastwaytrailer.com for faster and easier towing solutions.



Measuring with the trailer parallel gives the best, most accurate measurement.

Fastway SIMPLE WEIGH - Faster, Easier.™
fastwaytrailer.com



Use a block if needed to raise scale so the trailer can sit parallel to the ground.

533 South 1100 West
Provo, UT 84601

FASTWAY
TRAILER PRODUCTS®

SIMPLE WEIGH™

TONGUE WEIGHT SCALE

| Model | Maximum Capacity |
|------------|------------------|
| 88-00-3720 | 2,100 lb |

⚠ WARNING

Always chock the trailer wheels while using the SIMPLE WEIGH™ scale.

Always lower and remove weight slowly onto the SIMPLE WEIGH scale.

Always measure with the top of the scale seated fully in the coupler socket. Never measure from any other point on the trailer. Doing so may cause the scale to slip under load, resulting in injury and/or equipment damage.

Knowing your tongue weight does not assure safe towing.

Never retract the jack more than 1" above ground while the scale is in use and under load.

Never use with 5th wheel, gooseneck, or pintle type couplers. Use only to measure the tongue weight of bumper-pull trailers with a socket-type coupler.

Never leave the full trailer weight of the trailer for an extended period on the SIMPLE WEIGH.

The vehicle operator is responsible for adjusting the trailer, cargo, towing equipment and driving to ensure safe towing.

⚠ CAUTION

Always inspect the scale for damage before each use. Do not use a damaged scale.

Always remove the scale and support the trailer with the jack immediately after use.

Never load, unload, or move cargo while the tongue is being supported by the scale.



Never use the SIMPLE WEIGH scale in any way other than its intended purpose as a tongue weight scale.

Park the trailer to be weighed on a flat, level surface when using the SIMPLE WEIGH scale.

Place the scale exactly perpendicular to the ground while in use and under load.

The Fastway® SIMPLE WEIGH™ is the faster and easier trailer tongue weight measuring tool. Built to measure up to 2,100 lb., it is strong enough to handle even the heaviest of trailers. A mechanical spring ensures reliability and sustainability for years of hassle-free performance.

Most bumper-pull trailers should have a tongue weight that is 10% to 15% of the gross trailer weight. Adjust your trailer loading as needed to ensure the tongue weight and gross trailer weight are within the manufacturer's specifications. Do not exceed tow vehicle or trailer weight ratings.

Results of improper tongue weight include increased trailer sway, brake and/or axel fatigue, reduced driving and steering control and tow vehicle and trailer hitch damage or failure.

One Year Limited Warranty

Limited One-Year Warranty: Progress Mfg. Inc. warrants the SIMPLE WEIGH™ scale against latent defects in materials and workmanship under normal use and service, ordinary wear and tear is excepted, to the original owner for a period of 1 year from the first date of purchase at retail up to the value of its original purchase price. Accuracy is not guaranteed. Other conditions apply.

For complete warranty details and to submit a warranty claim visit: fastwaytrailer.com/warranty-registration or call Fastway Customer Support at 877-523-9103.